M2087 OPERATING INSTRUCTIONS

ENGLISH

ARMING: press the remote control button or wait for automatic arming. The red LED flashes, the turning indicators flash twice, door locking is activated if enabled, and the system is active after 25". If the buzzer* is enabled, it emits two BEEPS.

DISARMING: press the remote control button. The red LED goes off, the turning indicators flash once, and the door locking is released. If the buzzer* is enabled, it emits one BEEP.

ALARM MEMORY: if the red LED remains on after disactivation, then goes off at brief intervals, this means that one of the following alarms situations occurred during your absence: *ultrasound alarm/wire free sensors* (1 switch-off every 6"), *door alarm* (2 switch-offs every 6"), *bonnet/boot alarm* (4 switch-offs every 6"), or *self-powering, current absorption sensor, or key positive alarm* (8 switch-offs every 6"). If more than one alarm occurred, the indications are given in sequence every 6". The memory is reset when the key is turned in the ignition.

ULTRASOUND EXCLUSION: turn off the ignition key, open the driver's side door, and press the remote control button. The red LED flashes once. When the control unit is switched on, the red LED remains on for 25" to indicate that exclusion has been accomplished. If the buzzer* is enabled, 4 beeps are emitted. This selection is active for only one arming/disarming cycle.

ANTI CAR-HIJACKING: when the engine is started with the doors closed, the central locking is activated after 15", blocking any attempt to open the doors from the outside. When the engine is switched off or a door is opened from the inside, the central locking is automatically released. This function can be disactivated by pressing the remote control button with the engine on: the red LED flashes once to indicate disactivation.

TEMPORARY INHIBITION OF AUTOMATIC ACTIVATION (if enabled): press the remote control button after switching off the engine with the doors closed. The red LED flashes once to indicate inhibition of the automatic activation. Turning the ignition key re-enables automatic activation.

PANIC - HELP* FUNCTIONS (if enabled): press and hold down the PANIC/HELP button on the remote control for about 2". PANIC: The siren sounds at high power and the turning indicators flash. HELP*: The turning indicators flash twice to indicate that the function has been activated. After 60", the PANIC function is activated and the starter motor block is activated. Pressing the button again disactivates these functions. These functions do not alter the status of the control unit.

LOST REMOTE CONTROLS: to exclude the operation of remote control units that have been lost, carry out 16 consecutive commands (activation - disactivation) on the remote control without letting more than 8" pass between one transmission and the next. The fast flashing of the red LED indicates that you are in remote control enabling mode: carry out one transmission for each remote control unit in your possession by pressing the respective buttons. At each transmission, the turning indicators will respond with one flash. Wait 8", after which the system exits from this mode automatically. The remote controls that were not used are no longer able to command the control unit. To enable remote controls again, repeat the procedure described above using them while in remote control enabling mode.